

air sniper 



Air Sniper Elite Manual

Contents

Air Sniper Elite Maintenance manual	2
Warranty	2
How to set up your Unit	3
Connecting the unit to Wi-fi	4
How to name and group Units in the Dashboard system	5
How to group a unit	5
Filter Cleaning	6
Tools needed:	6
Element Cleaning	7
Tools needed:	7
Bulb change	8
Tools Needed:	8

Air Sniper Elite Maintenance manual

Thank you for purchasing and Air Sniper Elite. This manual provides step-by-step instructions of how to set up and take care of your new unit.

Replacement bulbs can be purchased on our website <https://www.airsniper.ca/product/36w-replacement-bulb/>

Videos of the instructions can be found on our website on the product page under maintenance videos or on our YouTube channel <https://www.airsniper.ca/>

Warranty

Limited Warranty Three Year Warranty Alpine Innovative Research Inc. (AIR) warrants the Air Sniper™ to be free from defects in the workmanship or materials under normal use and service (the “Warranty”) for a period of three (3) years (the “Warranty Period”) from the date of purchase through an AIR-authorized dealer/distributor. During the Warranty Period, should an Air Sniper™ be determined to be defective, AIR shall repair or replace the defective Air Sniper™ unit(s) (at AIR or dealer’s option) within a reasonable period.

Remedy Procedures If the Air Sniper™ proves defective within the Warranty Period, the purchaser may choose one of the following remedies, after contacting AIR for a Return Authorization Number: 1. Return the defective Air Sniper™ unit to the dealer/distributor from whom it was purchased together with a copy of the bill of sale, or dated proof of purchase thereof and the Return Authorization Number; or 2. Ship the defective Air Sniper™ unit directly to Air Alpine Innovative Research Customer Warranty Department along with the Return Authorization Number. Limitations

This Warranty is the only representation regarding the Air Sniper™, by Alpine Innovative Research Inc. of merchantability and fitness for use and shall extend to three (3) years from the date of purchase. The warranty excludes replaceable UVC bulbs. If it is determined by either Alpine Innovative Research Inc or an authorized dealer/distributor that the defect is the result of damage caused by the purchaser, the Warranty is null and void.

Contact Us Any questions or concerns pertaining to this Warranty may be directed to AIR by E-mail, telephone, or facsimile: AIR, Alpine Innovative Research.

Customer Warranty Department 3855 - 64th Avenue SE Calgary, Alberta, Canada T2C 2V5 Toll Free 1 (888) 338-9549 Fax 1 (403) 279-7738

How to set up your Unit

1. Carefully remove your Air Sniper Elite from the shipping carton and remove all exterior packaging.
2. If your unit requires wall-mounting unwrap the wall mount bracket and securely fasten it to the wall with screws.
3. If using a bracket carefully clip the back of the unit into the bracket.
4. Plug the unit into the power source (115V/60Hz or 230V/50Hz)
5. Once the unit is connected to a power source the touchscreen will light up.
6. The unit will begin at maximum speed to cycle the air out of the unit.
7. If there is bulb damage from shipping the bulb detector will display red.
8. Set the desired fan speed of the unit (this can be changed via the dashboard system or touchscreen anytime).
9. Listen to the unit for a typical fan sound if there are any “abnormal” sounds in the unit. If there are any abnormal sounds please turn the unit off immediately and contact the dealer or AIR, Alpine Innovative Research as damages may have occurred during transport.
10. Check the screen to see if there are any warning lights (bulb life, filter status) if all indicators present **green** or **Blue** the unit is cleaning your air effectively.

NoteThe unit effectively removes pathogens at all fan speeds. However higher fan speeds increase the airflow therefore, increasing the volume of air treated at a time. Increasing the fan speed also increases the noise of the unit.**



WARNING: Do not attempt to operate the UV-C lamps outside the unit. UV-C radiation is extremely harmful to unprotected (uncovered) eyes and skin

Connecting the unit to Wi-fi

All Air Sniper Elites version 2 can be connected to the local Wi-Fi network to allow remote monitoring and control of the unit.

Link to video: <https://www.youtube.com/watch?v=rX2rzQnqiCM>

How to use touchscreen Video: <https://www.youtube.com/watch?v=rX2rzQnqiCM>

1. Ensure the unit is turned on.
2. Locate the Wi-Fi button on the touchscreen (between the moon and the settings button)
3. Press the Wi-Fi button to access the network screen.
4. Click on **Set up Wi-Fi**
5. The unit will then give you an option to select a network.
6. Choose the network that you would like to connect the unit to.
7. Enter the password for the network (if applicable)
8. The Wi-Fi button will turn **blue** when connected and display the current strength of the unit.

How to name and group Units in the Dashboard system

Air Sniper units may be named anything the customer would like with the dashboard system.

Note* To Set up your dashboard system AIR will send you a time sensitive invite to access it initially. Please contact us to do so once the units have been connected to a wi-fi network.**

Link to video: <https://www.youtube.com/watch?v=9F-BAeLnKSc>

1. Log into your Air Sniper dashboard.
2. Note the default name for the unit is the serial number (located on the sticker on the side of the unit).
3. Locate the unit in the unassigned group.
4. Expand the device by clicking on the search icon with the + beside the serial number of the unit.
5. Scroll over to the **Device attributes** section (located on the right-hand side of the section)
6. Click on the **Name** box.
7. Enter the name you would like to choose for the unit.
8. Click **Submit** and the unit will now show the name chosen in the dashboard.
9. To change the name of the unit simply repeat the steps and enter a different name.
***Note- the serial number of the unit can still be found under the “about” section by expanding the unit information (click the search button with the +)**

How to group a unit

1. Log into your Air Sniper dashboard.
2. If the unit is not grouped it will appear by default in the **unassigned group**.
3. Expand the device by clicking on the search icon with the + beside the name or serial number of the unit.
4. Scroll over to the **Device attributes** section.
5. Click on the box that says **group**
6. Enter the name of the group you would like to place the unit in.
7. Click **submit** and the unit will appear in the group you have selected.
8. To **Remove** a device from the group, repeat the steps and delete the name of the group then press **Submit**.

Filter Cleaning

The Filter on your Air Sniper Elite will need cleaning when the dashboard or touchscreen indicates the filter status is red or about to turn red.

Link to video: <https://www.youtube.com/watch?v=EpRY6dLdFzQ>

****Please note this is the ultra video link the procedure is the same for all wall-mounted units. The only difference is number of filters and elements.**

Tools needed:

- Vacuum or Air Compressor
1. Turn off your Air Sniper Elite. The power button can be found on the touchscreen. When the unit is off the button will turn from green to **White**.
 2. Unplug unit from the power source
 3. Locate the front panel (filter maintenance can be done while the unit is still on the wall.)
 4. Lower the front panel of the unit using the black knob.
 5. Locate the **black** pre-filter on the inside of the panel.
 6. Remove the black pre-filter.
 7. Locate the mesh panel to access the inner pre-filter.
 8. Remove the mesh panel to access the **black** inner pre-filter.
 9. Remove inner pre-filter by gently grabbing a corner and removing it from the frame.
 10. Use a vacuum or compressed air to clean the two **black** pre-filters. Ensure both sides are cleaned to remove particulates.
 11. Clean the mesh panel. Vacuum or use compressed air to remove any particulates from the mesh panel.
 12. Re-insert inner **black** pre-filter in the metal frame. Ensure all corners and sides are back in the frame by gently pushing it into place.
 13. Re-insert mesh panel. Replace the mesh panel in front of the inner black pre-filter with the flat side facing you.
 14. Re-insert outside pre-filter in front panel. Slide the front panel pre-filter back into place. Ensure all corners and sides are in place before closing the panel.
 15. Close and lock front panel. Once both pre-filters have been cleaned and put back into place close the panel and tighten the knob.
 16. Plug the unit back in.
 17. Turn unit back on (the power button will turn **green**).

Resume cleaning your air!

Element Cleaning

The Elements of your Air Sniper Elite are located on the inside of your unit. There is a total of **4 elements** located in your Air Sniper Elite. The elements should be cleaned approximately every 18 months (we recommend cleaning the elements when changing the bulbs)

Link to video: <https://www.youtube.com/watch?v=xYPSgMpiplU>

*****Please note this is the Ultra Video Link. The procedure is the same for all wall-mounted units. The only difference is the number of elements inside the unit.**

Tools needed:

- Flat head screwdriver
 - Vacuum or Air compressor
1. Turn off your Air Sniper Elite. The power button can be found on the touchscreen. When the unit is off the button will turn from green to **white**.
 2. Unplug the unit from the power source.
 3. Position the unit so that the side with the **touchscreen** is facing you.
 4. Locate the quarter-turn fasteners on the unit. There is a **total of 7 fasteners** to remove the panel.
 5. Using the flat head screwdriver turn the fasteners counter-clockwise once.
 6. Gently remove the panel.
 7. Locate the **4 elements** in between each set of bulbs.
 8. Slowly Slide all **4 elements** out of the unit.
 9. Once all elements are removed, vacuum both sides of the elements. If using compressed air, ensure that particulates are blown from the inside (the side with raised edges)
 10. Re-insert elements ensuring the raised edge is facing the front end of the unit. (the end with the black knob)
 11. Replace the panel on the unit.
 12. Tighten the quarter-turn fasteners.
 13. Plug the unit back in.
 14. Turn the unit back on (the power button will turn **green**)

Resume cleaning your air!

Bulb change

The Bulbs in your Air Sniper Elite will need to be changed every **18 Months**. The Bulb life of the units can be monitored through the dashboard or via the touchscreen on the unit.

You can order new bulbs directly from the dashboard or from our website:

<https://www.airsniper.ca/product/18w-replacement-bulb-low-base/>

Note: A reset code will be required when changing the bulbs. Air Sniper will provide this code with the purchase of bulbs.

Tools Needed:

- 6 x 36-watt bulbs purchased from Air Sniper
- Flat head screwdriver

1. Turn off your Air Sniper Elite. The power button is located on the touchscreen. The button will turn from green to **white** when the unit is turned off.
2. Unplug the unit from the power source (allow 20-30 minutes for the unit to cool off before touching bulbs).
3. Position the unit so that the side with the **touchscreen** is facing you.
4. Locate the quarter-turn fasteners **there is a total of 7 to remove the panel** (three on each side, one on the bottom)
5. Using a flat head screwdriver turn the fasteners **Counter-Clockwise** once.
6. Gently remove the panel to access the bulbs.
7. Locate the metal bulb retainers at the base of each bulb.
8. Remove the first metal retainer (located at base of bulb).
9. Remove the old UV Bulb.
10. Repeat steps 8,9 with all the bulbs in the row.
11. Repeat with all 3 rows.
12. Insert new bulb into the last space at the back (ensure it clicks into slot).
13. Slide the metal retainer back until it clips on top of the new bulb.
14. Repeat moving back to front until all rows are completed.
15. Place the cover back on the unit.
16. Tighten the fasteners **(total of 7)**
17. Plug unit back in.
18. Turn unit back on.
19. Enter reset code provided with purchase of bulbs.

Resume cleaning your air!